


Waveguide Adapter Part Numbering

□: for English Letter ○:For Numeral



(1) code:

W: for Waveguide Category

(2) code:

Category

R	Rectangular	D	Double Rigid
C	Circular		

(3) (4) code:

Structure

AA	Adaptor, General	AB	Adaptor, End Launch
----	------------------	----	---------------------

(6) (7) (8) code:

Frequency (GHz)

975	0.75-1.12	770	0.96-1.45	650	1.12-1.70	510	1.45-2.20
430	1.70-2.60	340	2.20-3.30	284	2.60-3.95	229	3.30-4.90
187	3.95-5.85	159	4.90-7.05	137	5.85-8.20	112	7.05-10.00
102	7.00- 11.00	090	8.20-12.40	075	10.00-15.00	062	12.40-18.00
051	15.00-22.00	042	18.00-26.50	034	20.00-33.00	028	26.50-40.00

(9) code:

Flange Type

A	Square Cover type	B	CMR	C	CPR Type
---	-------------------	---	-----	---	----------

(10) (11) code:

Plating

NX	N Type	SA	SMA	29	2.92mm
24	2.4mm	35	3.5mm		

(14) code:

Material

A	AL6061	C	Copper
---	--------	---	--------

(15) code:

Finish

0	RoHS Plating
---	--------------

(16) code:

Packing

X	Standard	A	Others Package
---	----------	---	----------------